

Polycom Soundpoint 550 Quick User Guide

Call Transfer

During a call, press the Transfer or Trnsfer soft key. The call is placed on hold.

Press the number to which you want to transfer the call

You can talk privately to the party to which you are transferring to before the transfer is completed. The transfer can be completed by hanging up or pressing the Transfer or Trnsfer soft key.

Blind Call Transfer

During a call, press the Transfer or Trnsfer soft key.

Press the **Blind** soft key



Enter the number to which you want to tranfer the call

Transfer direct to voicemail


To transfer directly to someones voicemail, preface the number to which you are performing a blind transfer to with *86 (Example *863500)

Set up a Conference Call

Call the first party.

Press Conference or Confrnc soft key to create a new call

The active call is placed on hold.



Call the second party

When the second party answers, press the Conference or Confrnc soft key again to join all parties.

To add another party, repeat step 2.


To split a Conference Call

From the active conference page, press the **More** key, and then the **Split** soft key to split the conference.

Enabling Do Not Disturb

Press Do Not Disturb

A flashing icon and text on the graphic display indicate that Do Not Disturb is enabled.



Calls received while **DND** is enabled are logged in missed calls unless otherwise directed.

To disable, press Do Not Disturb

Paging

Press *401 on the keypad.

This will connect you to the paging system

Call Park

During a call, press **Trnsfer** soft key, then press the **Blind** soft key.

Press *77 then a two digit park zone.

Example: *7701

Press the Send soft key.

To pick up a call, lift any handset within the park group and press *77, then the park zone the call was given and press the **Send** soft key.

Voicemail

To retrieve voicemail messages, press the Messages key or press *86 on the keypad.

At the prompt, enter your password and enter 1 to review messages.

Place a call on Hold

To place a call on hold, press the (Hold) key.



Press Hold again or the **Resume** soft key to resume the call.

